Brass Hatch Corduroy Strip BH2 400mm





Available with either a round or square end

4 Colour options

316L S/S - Bronze - Aluminium Full installation service

Brass Hatch Corduroy Strip BH2 400mm - Installation



Installation Welded Pin

- 1. Drill holes 7mm dia x 16mm depth.
- 2. Remove dust and debris caused by drilling.
- 3. Following the product guidelines, screw the nozzle on, and press the trigger the two part resin will mix in the nozzle. Pour a sufficient amount to fill the drilled hole.
- 4. Push the stud into the hole firmly ensuring an edge seal around the entire stud
- 5. Allow a few minutes for the Polymer Modified Adhesive to set.

Installation Machined Pin

- 1. Drill holes 7mm dia x 13mm depth.
- 2. Remove dust and debris caused by drilling.
- 3. Following the product guidelines, screw the nozzle on, and press the trigger the two part resin will mix in the nozzle. Pour a sufficient amount to fill the drilled hole.
- 4. Push the stud into the hole firmly ensuring an edge seal around the entire stud
- 5. Allow a few minutes for the Polymer Modified Adhesive to set.

Installation Self Adhesive

- 1. Prep area where stud is to be situated by using a grease and dirt remover, i.e white spirits. Then let dry thoroughly.
- 2. Once area is dried, peel backing to stud off and press down firmly.

Note: We highly recommend only using the self-adhesive studs on tiled floors.

For layout suggestions please refer to the below.

https://www.studmarc.com/knowledge-base/how-far-apart-should-tactile-studs-be-installed-from-each-other/



Brass Hatch Corduroy Strip BH2 400mm



