# SS 316L Diamond Corduroy Warning Strip SH2 400mm





4 Colour options

Brass - Bronze - Aluminium Full installation service

# SS 316L Diamond Corduroy Warning Strip SH2 400mm - Installation



#### **Installation Welded Pin**

- 1. Drill holes 7mm dia x 16mm depth.
- 2. Remove dust and debris caused by drilling.
- 3. Following the product guidelines, screw the nozzle on, and press the trigger the two part resin will mix in the nozzle. Pour a sufficient amount to fill the drilled hole.
- 4. Push the stud into the hole firmly ensuring an edge seal around the entire stud
- 5. Allow a few minutes for the Polymer Modified Adhesive to set.

## **Installation Machined Pin**

- 1. Drill holes 7mm dia x 13mm depth.
- 2. Remove dust and debris caused by drilling.
- 3. Following the product guidelines, screw the nozzle on, and press the trigger the two part resin will mix in the nozzle. Pour a sufficient amount to fill the drilled hole.
- 4. Push the stud into the hole firmly ensuring an edge seal around the entire stud
- 5. Allow a few minutes for the Polymer Modified Adhesive to set.

## **Installation Self Adhesive**

- 1. Prep area where stud is to be situated by using a grease and dirt remover, i.e white spirits. Then let dry thoroughly.
- 2. Once area is dried, peel backing to stud off and press down firmly.

Note: We highly recommend only using the self-adhesive studs on tiled floors.

## For layout suggestions please refer to the below.

https://www.studmarc.com/knowledge-base/how-far-apart-should-tactile-studs-be-installed-from-each-other/



# SS 316L Diamond Corduroy Warning Strip SH2 400mm



